



Best Practices for Installing RAID on Vicon Dell Servers

Ensuring Effective Surveillance through Proper Installation

Introduction:

Implementing RAID on Vicon Dell servers is essential for enhancing data storage performance and reliability. This guide outlines best practices for configuring RAID levels, selecting compatible hardware, and ensuring proper environmental conditions. By adhering to these guidelines, organizations can optimize their RAID installations, minimize downtime, and safeguard data integrity on Vicon Dell server systems.

Assess Requirements: Before proceeding, understand the specific needs of your organization regarding data storage, performance, and redundancy.

Choose RAID Level: Select the appropriate RAID level based on your requirements. Common options include RAID 0, RAID 1, RAID 5, RAID 6, RAID 10, etc. Each RAID level offers different trade-offs between performance, redundancy, and capacity.

Select Compatible Hardware: Selecting compatible hardware is crucial for a successful RAID installation on Vicon Dell servers. When considering hard drives for your RAID configuration, the IronWolf Pro series offers a range of options suitable for various storage requirements, with capacities ranging from 2TB up to 24TB. Engineered to deliver 24x7 performance, reliability, and dependability, IronWolf Pro drives are specifically designed for use in multi-bay, multi-user commercial, and enterprise RAID storage solutions. These drives provide total peace of mind for your storage infrastructure needs.

Update Firmware and Drivers: Before installation, ensure that the server's firmware and RAID

controller drivers are up to date. You can refer to this link: <https://www.dell.com/support/kbdoc/en-uk/000128194/updating-firmware-and-drivers-on-dell-emc-poweredge-servers>

Backup Data: Backup all existing data on the server before initializing RAID configuration by using Valerus VMS to prevent data loss in case of errors during the setup process. This process is referred to in this link: https://www.vicon-security.com/wp-content/uploads/2021/04/Valerus-User-Guide_Ver20R3-rev12.pdf

Configure RAID Controller: Access the RAID controller configuration utility during the server boot process (usually by pressing a specific key combination, such as Ctrl+R for PERC controllers). Create RAID arrays according to your chosen RAID level and configure additional settings such as stripe size, cache policy, and disk initialization. More information refers to this link: <https://www.dell.com/support/contents/en-uk/videos/videoplayer/how-to-configure-raid-with-device-settings-lifecycle-controller-for-poweredge/6320378969112>

Hot Spare Configuration: Consider configuring hot spares to automatically replace failed drives in the RAID array, ensuring continuous operation and minimizing downtime.

Monitor RAID Health: Utilize Dell OpenManage or other monitoring tools to regularly check the health and status of the RAID array. Set up alerts for critical events such as disk failures or degraded array status.

Regular Maintenance: Implement a regular maintenance schedule to inspect the server hardware, including hard drives and RAID controller, for signs of wear or potential failures. Replace faulty components promptly to maintain system reliability.

Document Configuration: Document the RAID configuration, including RAID level, drive layout,



and controller settings, for future reference and troubleshooting purposes.

Test Failover Procedures: Periodically test failover procedures to ensure that the RAID array can withstand drive failures without data loss or service interruption. Simulate drive failures and verify that the hot spare activates as expected.

Secure Physical Access: Ensure that the server is physically secured to prevent unauthorized access or tampering with the RAID configuration.

Environmental factors and physical installation conditions

Temperature Control: Ensure that the server room or data center maintains a stable temperature within the recommended range specified by Dell for your Vicon server model and RAID components. Typically, this temperature range is between 10°C to 35°C (50°F to 95°F). Use cooling systems such as air conditioning or server room ventilation to maintain optimal temperatures.

Humidity Management: Maintain proper humidity levels within the server room to prevent moisture-related damage to RAID components. Aim for a relative humidity level between 20% to 80% to avoid condensation and corrosion. Dehumidifiers can help control humidity levels if necessary.

Dust and Particle Control: Minimize dust and airborne particle accumulation in the server room or data center to prevent them from entering and clogging RAID unit components, such as cooling fans and vents. Use air filtration systems and regular cleaning routines to keep the environment clean.

Physical Security: Ensure that the server rack housing the RAID units is in a secure area with restricted access to authorized personnel only. Use locking server cabinets or cages to prevent unauthorized tampering or theft of RAID components.

Vibration and Shock Protection: Install RAID units in server racks or enclosures designed to absorb and minimize vibrations and shocks. Avoid placing heavy equipment directly above or below the server rack to prevent structural damage from vibrations.

Power Conditioning: Use uninterruptible power supply (UPS) systems to provide clean and stable power to the server and RAID units, protecting them from power surges, fluctuations, and outages. Ensure that UPS systems are properly sized and maintained to meet the power requirements of the server infrastructure.

Cable Management: Organize and route cables neatly within the server rack to maintain airflow and prevent accidental disconnection or damage to RAID unit connections. Use cable management accessories such as cable trays, ties, and labels for efficient cable routing and identification.

Regular Maintenance: Implement a regular maintenance schedule to inspect and clean RAID units, server racks, cooling fans, and air vents. Check for signs of dust buildup, overheating, or component wear and replace or repair as needed.

Monitoring and Alerts: Utilize server and RAID monitoring tools to track temperature, humidity, power consumption, and other environmental parameters in real-time. Set up alerts for abnormal conditions or potential hardware failures to enable proactive troubleshooting and maintenance.

Disaster Preparedness: Develop and implement a disaster recovery plan that includes backup and restoration procedures for critical data stored on RAID arrays. Regularly test backup integrity and recovery processes to ensure readiness in case of data loss or system failure.

By adhering to these environmental and physical installation best practices, you can ensure the optimal performance, reliability, and longevity of RAID units in Vicon Dell server installations.